

地址:台南市安平區 70848 永華路二段 501 號 8F-3 電話: +886 6 299 9628 傳真:+886 6 299 0638

Mail: grand\_svc@guanden.com.tw



## **Rotary Drum DIN Abrasion tester**

























# INNOVATIONS IN RUBBER TESTING





## MonTech ABR 3000 Rotary Drum DIN Abrasion tester

#### **Abrasion Tester ABR 3000**

The MonTech rotary drum abrasion tester in accordance with DIN 53516, DIN ISO 4649, AS1683.21 and ASTM D 5963 makes abrasion testing really easy. The test specimen is fixed into a quick clamp sample holder and precisely guided - either with or without rotation - over a predefined distance of either 20 or 40 Meters and with a defined load on a sheet of abrasive paper mounted to a stainless steel rotary drum of 150 mm diameter. The drum rotates with a speed of 40 rpm. Finally the frictional loss is calculated by comparing the sample weight before and after testing.

The MonTech ABR 3000 Abrasion tester is a tear testing instrument for determination of the resistance of elastomers in regards to the frictional loss of a rotating or fixed specimen.

- → **Standards** DIN 53516, ISO/DIN 4649, AS1683.21, ASTM D 5963
- Description The test is made on materials which wear off or abrade, e.g. tires, belts, conveyor belts, shoe soles.
- Basic equipment Stiff aluminum machine frame with brushless drive system and specimen holder, abrasion drum, metal housing, electric motor for rotation of the drum and the specimen holder

The working area is protected with translucent cover and protective safety switch. The specimen holder has a integrated dead weight of 2.5 N. Additional loading weights of 2.5 N and 5.0 N are supplied as standard accessories. Optionally additional loadweights as well as accessories such as drum cleaning, heating or wet testing are available.

#### **Test Procedure:**

- After determination of the abrasiveness of the abrasion sheet, the
  instrument is ready for testing. Samples can easily be drilled out of a
  rubber sheet or final product with the optional circular cutting knife.
  Typically tests are performed at ambient temperature of 23 ± 5°C or
  with the optional drum heating at elevated temperatures.
- 2. Initially the weight of the test specimen is measured
- 3. Afterwards the sample is mounted into the sample holder, the desired abrasion distance is set and the load weights are applied. The instrument cover is closed and the test is started by a simple click on the start button. The rotation of the drum will start and the specimen will be moved over the abrasive sheet. Once the pre-set abrasion distance is reached, the instrument will stop automatically.
- After the test run is finished, the sample is removed from the sample holder and the weight of the sample after abrading is measured.
- 5. For calculation of the abrasion, the mass loss (average value of 3 to 10 single values) is converted to the loss of volume by help of the density and corrected for the deviation of the abrasiveness of the abrasion sheet from the set value of abrasiveness.
  Formula: Abrasion= mass lost x 200 specific weight x abrasiveness



#### **Technical specification**

Technical specification	
International standards	DIN 53516, DIN ISO 4649:2002 (E), AS1683.21, ASTM D 5963
Contact pressure for specimens expandable up to	N 2.5 5.0 7.5 10.0 N 12.5 15.0 17.5 20.0
Diameter of drum	150 mm
Length of drum	460 mm
Drum speed	40 min-1
Peripheral speed of drum with abrasion sheet	0,32 m/s
Dimensions of abrasion sheet L/W	472.5 mm (+2) x 400 mm
Film tape W/D	50 mm x 0.2 mm
Abrasion distance of specimen	40 m (20 m)
Corresponds to roller rotations	84 (42)
Angle of inclination of axle center of the specimen to vertical position of the drum	3 degree
Granulation of abrasion sheet	60 mesh
Specimen diameter	16 mm
Specimen thickness	6 15 mm
Maximum gripping length of specimen	16 mm
Lateral feed of specimen per drum rotation	4.2 mm
Number of revolutions of specimen holder for rotating specimen	0,9 min-1
Dimensions (H x W x D)	370 mm x 760 mm x 430 mm
Weight	about 50 kg net
Electrical	90-250 V, 1 Amp, 47-63 Hz, Single phase
Optional items	- Additional load weight 10 N - Analytical balance, 1 mg or 0.1 mg - Heated drum - Wet abrasion testing (spray/basin) - Drum cleaning unit - Circular sample cutter, diameter 16 mm - Standardized test elastomer specimen according to ISO 4649 and ASTM D 5963 - Set of emery papers / abrasion sheets

#### Scope of supply:

- → Abrasion tester ABR 3000
- $\,\rightarrow\,$  Set of emery papers / abrasion sheets
- → Roll of adhesive tape
- ightarrow Set of brushes
- → Safety cover
- ${\color{red} \boldsymbol{\rightarrow}} \ \ \text{Gauge and blunting sample}$
- → Standard accessories



Load weight system



Quick clamp sample holder



Accessories and optional items



## **Rotary Drum DIN Abrasion tester**

























### MonTech

Werkstoffprüfmaschinen GmbH Carl - Benz - Straße 11 D - 74722 Buchen / Germany Phone: +49 (0)6281 562230

Fax: +49 (0)6281 562255

info@rubber-testing.com

www.rubber-testing.com



